SUP modulating quick configuration flowchart

Use ◁ or ▷ to change the **temperature rise in electric heat mode**

Use ◁ or ▷ to change the **temperature rise in autobackup mode**

Use ◁ or ▷ to **activate/deactivate autobackup**

Use ◁ or ▷ to change the **max power ratio**

Use ◁ or ▷ to change the **CFM per TON in de-humidification**

Use ◁ or ▷ to change the **CFM per TON in heating**

Use ◁ or ▷ to change the **CFM per TON in cooling**

Use ◁ or ▷ to change **Fan ON speed**

Use ◁ or ▷ to adjust the **balance point**

X00485